

# Blinds

Variante Tast 4		
△	UP (Element)	
▽	DOWN (Element)	
	Reserve (Szene)	
	Reserve (Szene)	

# T4


For additional shutters or scene for light.

Function: Press briefly, pulse  
Press for longer than 3 sec. Blinds move UP/DOWN in desired direction in 180 sec.

e.g. Feller Editio white 323226000




LIGA.AIR.STO.240



LIGA.AIR.STO.2T.240



LIGA.AIR.4.STO.240



## Variante Tast 8 to 2 Pushbuttons

△	UP Blind 1	
▽	DOWN Blind 1	
△	UP Blind 2	
▽	DOWN Blind 2	

△	UP Blind 3	
▽	DOWN Blind 3	
△	UP Central	
▽	DOWN Central	



LIGA.AIR.TAST8.240

Blinds / Shutters 1-3  
Program as elements

Function: Centrally programmed animation  
i.e. All blinds UP 50 sec.  
All blinds DOWN 50 sec.  
(See Tips + Tricks)

e.g. Feller Editio white 323226000

## Variante Tast 8 to one Pushbutton

△	UP Blind 1 DOWN	▽
Scene 1                      Scene 2		
Scene 3                      Scene 4		

1 piece Push-button 8 is sufficient.  
T1-T6 occupied (blinds/light)  
T7-T8 reserve

e.g. Feller Editio white 323227000



LIGA.AIR.TAST8.240

Anschlusschema: LIGA air Baustein

Leuchtenmodell: ...

Steuerung: Steuermodul Storen ohne Taster

LIGA.AIR.STO.240

V1.4 / 06.12.2021



**LIGA AIR**

LICHTTEAM AG  
Stationsstrasse 89  
CH-6023 Rothenburg  
SWITZERLAND

+41 41 280 57 57  
mail@ligaair.ch  
www.ligaair.ch

