



ATTENTION: For metal blind boxes, be sure to observe the Bluetooth range.



Operation:
Program max UP or max DOWN on a button in the Casambi app.

If this button is pressed for longer than 4 seconds, an action of max. 5 minutes takes place.



Wiring Diagram: LIGA air module
Luminaire Model: ...
Control: Shutter Module without Push-Buttons

LIGA.AIR.STO.240
V1.5 / 26.07.2022



LIGA AIR

LICHTTEAM AG
Stationsstrasse 89
CH-6023 Rothenburg
SWITZERLAND

+41 41 280 57 57
mail@ligaair.ch
www.ligaair.ch



Blinds

Variante Tast 4		
△	UP (Element)	
▽	DOWN (Element)	
	Reserve (Szene)	
	Reserve (Szene)	

T4


For additional shutters or scene for light.

Function: Press briefly, pulse
Press for longer than 3 sec. Blinds move UP/DOWN in desired direction in 180 sec.


e.g. Feller Editio white 323226000




LIGA.AIR.STO.240



LIGA.AIR.STO.2T.240



LIGA.AIR.4.STO.240



Variante Tast 8 to 2 Pushbuttons

△	UP Blind 1	
▽	DOWN Blind 1	
△	UP Blind 2	
▽	DOWN Blind 2	

△	UP Blind 3	
▽	DOWN Blind 3	
△	UP Central	
▽	DOWN Central	



LIGA.AIR.TAST8.240

Blinds / Shutters 1-3
Program as elements

Function: Centrally programmed animation
i.e. All blinds UP 50 sec.
All blinds DOWN 50 sec.
(See Tips + Tricks)


e.g. Feller Editio white 323226000

Variante Tast 8 to one Pushbutton

△	UP Blind 1 DOWN	▽
Scene 1 Scene 2		
Scene 3 Scene 4		

1 piece Push-button 8 is sufficient.
T1-T6 occupied (blinds/light)
T7-T8 reserve

e.g. Feller Editio white 323227000



LIGA.AIR.TAST8.240

Wiring Diagram: LIGA air module
Luminaire Model: ...
Control: Shutter Module without Push-Buttons

LIGA.AIR.STO.240
V1.5 / 26.07.2022



LIGA AIR

LICHTTEAM AG
Stationsstrasse 89
CH-6023 Rothenburg
SWITZERLAND

+41 41 280 57 57
mail@ligaair.ch
www.ligaair.ch

